

SAFETY & TECHNOLOGY ORGANIZER

OCTOBER 2012

ENCLOSED

Safety Topic: "Filling Liquefied Products"

Please contact GAWDA's OSHA and EPA Consultant, Mike Dodd for more information.

Traffic Bulletin: "Cylinders – Required Markings"

Please contact GAWDA's DOT and Security Consultant, Mike Dodd for more information.

Medical Gas Bulletin: FAQs, Medical Gas Roundtables, and Micro-audit

Please contact GAWDA Medical Gas Consultant, Tom Badstubner for more information.

GAWDA is pleased to distribute this information to: Distributor and Supplier Key Contacts and all Compliance Manual Owners. Please carefully review this mailing and be sure the information is passed to the appropriate person within your organization. Timely Safety data is a benefit of Membership in GAWDA





SAFETY TOPIC

OCTOBER 2012

Safety Meetings are important!

They: get your employees actively involved encourage safety awareness help identify problems before they become accidents motivate employees to follow proper safety procedures

We are happy to provide you with a monthly topic for your agenda.

ROUTE TO:	
	General Manager
	Safety Coordinator
	Supervisor Dept
	Other
	Date of Meeting

Filling Liquefied Products

Many of our members fill carbon dioxide cylinders and some fill nitrous oxide. Here are some suggestions to consider when filling these and other liquefied (liquid in the cylinder at room temperature) products. This is not a complete checklist. Please refer to the several CGA pamphlets on the product and the filling of cylinders. As a reminder, if you have not already signed up, please check out the "CGA & GAWDA Subscription Program" at this website: http://www.cganet.com/customer/gawda.aspx

Some suggested CGA pamphlets to read are G-6.3, "Carbon Dioxide Cylinder Filling and Handling Procedures" and P-15, "Filling of Industrial and Medical Nonflammable Compressed Gas Cylinders".

Carbon Dioxide and Nitrous Oxide Filling

- Check the ownership, DOT or ICC specification number, pressure rating, retest date, and label for gas service.
- Check for serious damage such as cracks and harmful dents, gouges, arc burns, fire burns, excessive corrosion, etc., and the need for repainting.
- Check for oil, grease, and other contaminates on the valve, neck ring, and cylinder exterior.
- Check the valve outlet and outlet connection for cleanliness. Check for thread damage. (Remember that racing nitrous uses a CGA 660 valve.)
- Check the pressure release device for damage and proper pressure rating.
- Check for the presence of contaminants in the cylinder. (No odor test for health reasons.)
- Vent and evacuate as required to ensure the absence of contaminants.
- Dead ring test (hammer test)
 - o Required for Nitrous Oxide to go 10 years on retest.
 - o Not required but recommended for steel CO2 cylinders.
- All cylinders should be tare weighted.
- All cylinders should be checked on the scale to verify the cylinder tare weight prior to hooking up the fill lead.
 - Any cylinder over the tare weight should be checked for residual product or foreign material inside the cylinder. (A common item is water or beverage syrup inside CO2 cylinders.)
 - Any cylinder under the tare weight could indicate loss of metal due to corrosion.



SAFETY TOPIC

- No fusible metal backed safeties. (The presence of fusible metal backed safeties has extreme fatality potential with liquefied products.)
- Any pure CO2 cylinders or cylinders with mixtures greater than 30% CO2 must have the "star" peened out of the last retest date. (49 CFR 180.209 (b)(3))
- Fill by weight and do not exceed the maximum filling density for the product and size (water capacity) of the cylinder.
- Check to make sure that you have a proper decal with none of the words missing and the colored diamond is complete and not faded. For products that chill the cylinder during the filling process, you will need to affix the decals prior to filling.
- Secure the cylinder cap if it has provisions for a cap.

If the cylinder is marked with DOT E (exemption) or DOT SP (special permit), then the provisions of the permit must be followed. Also, you must train your employees involved with the permit every 3 years on the provisions of the permit and document the training per 172.704.

As always, if there are questions or items that I can help you with, please don't hesitate to contact me.

Michael Dodd GAWDA DOT, Security, OSHA, and EPA Consultant MLD Safety Associates, LLC P.O. Box 93 Poplar Bluff, MO 63902 (573) 718-2887

Email: MLDSafety@hotmail.com





October 2012

Cylinders - Required Markings

Following up on the recent alert that was published on MC acetylene cylinders that have been found without proper DOT markings, I thought it would be to remind people of the markings that are required on our cylinders in order for us to fill and ship them in the USA.

Here is the alert that was put out on MC cylinders: "CGA has brought to my attention that there are MC acetylene cylinders being sold in the USA that do not have the DOT required markings on them. The fastest thing to look for is the required cylinder specification markings of DOT 8 or DOT 8AL. If these are brought to you for exchange, you should refuse them because we are not allowed to refill and place these back into commerce in the USA without all the required markings. If you exchange these, then you will be giving away a good cylinder for one that you can't use."

Required Markings

178.35 General requirements for specification cylinders.

- (f) Markings. Markings on a DOT Specification cylinder must conform to applicable requirements.
- (f)(1) Each cylinder must be marked with the following information:
- (f)(1)(i) The DOT specification marking must appear first, followed immediately by the service pressure. For example, DOT-3A1800 or ICC-3A2015.
- (f)(1)(ii) The serial number must be placed just below or immediately following the DOT specification marking.
- (f)(1)(iii) A symbol (letters) must be placed just below, immediately before or following the serial number. Other variations in sequence of markings are authorized only when necessitated by a lack of space. The symbol and numbers must be those of the manufacturer. The symbol must be registered with the Associate Administrator; duplications are not authorized.
- (f)(1)(iv) The inspector's official mark and date of test (such as 5-95 for May 1995) must be placed near the serial number. This information must be placed so that dates of subsequent tests can be easily added. An example of the markings prescribed in this paragraph (f)(1) is as follows:

DOT-3A1800 1234 XY





AB 5-95 Or:

DOT-3A1800-1234-XY AB 5-95

Where:

DOT-3A=specification number

1800=service pressure

1234=serial number

XY=symbol of manufacturer

AB=inspector's mark

5-95=date of test

- (f)(2) Additional required marking must be applied to the cylinder as follows:
- (f)(2)(i) The word "spun" or "plug" must be placed near the DOT specification marking when an end closure in the finished cylinder has been welded by the spinning process, or effected by plugging.
- (f)(2)(ii) As prescribed in specification 3HT (§178.44) or 3T (§178.45), if applicable.
- (f)(3) *Marking exceptions.* A DOT 3E cylinder is not required to be marked with an inspector's mark or a serial number.
- (f)(4) Unless otherwise specified in the applicable specification, the markings on each cylinder must be stamped plainly and permanently on the shoulder, top head, or neck.
- (f)(5) The size of each marking must be at least 0.25 inch or as space permits.
- (f)(6) Other markings are authorized provided they are made in low stress areas other than the side wall and are not of a size and depth that will create harmful stress concentrations. Such marks may not conflict with any DOT required markings.

UN Cylinders

UN cylinders have been approved for use in the United States and they will have a completely different set of markings on them. There is an excellent brochure from DOT that explains the markings and what each mark means at this website:

http://www.phmsa.dot.gov/staticfiles/PHMSA/DownloadableFiles/Files/PHH50 0078 07 06 UN Cylinders.pdf

The key for us with UN cylinders is to find the letters USA immediately in front of the manufacturer's mark as explained in the brochure.





If there are any questions regarding this Bulletin, please contact:

Michael Dodd GAWDA DOT, Security, OSHA & EPA Consultant P.O. Box 93 Poplar Bluff, MO 63902 (573) 718-2887

Email: MLDSafety@hotmail.com





10/01/2012

Frequently Asked Questions

Q - Is Aviator Breathing Oxygen (ABO) a medical gas?

A - No. ABO is not a medical gas. However there are some specific impurities that are important for aviator breathing applications. If you would like some sample procedures and test specifications, just let Tom Badstubner know.

October Medical Gas Roundtable (10/05/2012) – CGMP - High Pressure Prefill Inspection and Filling High Pressure Cylinders

These GAWDA Medical Gas roundtables are excellent sources of CGMP training and the latest industry compliance news. In October we will be discussing basic procedures to conduct a prefill inspection and how to fill medical high pressure cylinders.

For your information, we are also conducting the following webinars in August:


- *QSR/ISO* 17025 Complaints, Non-Conformances, Corrective Action/Preventive Action (CAPA)
- Specialty Gas Measuring and Controlling Analytical Uncertainty (ISO 6143)

These and other webinars are available as a streaming recording at a time convenient to you. If you are unable to view the webinar live, just let us know and we will send you the link to the recording. If you would like to receive invitations to the training webinars, just send an email to juliet@asteriskllc.com.

Professional Compliance Seminars

The GAWDA Professional Compliance Seminar series has one more sessions in 2012:

☐ Central Region - Aurora, IL - October 2 - 4, 2012 (Weldcoa/Precision University)



These seminars provide certified and documented training about DOT, OSHA, FDA and plant operations. Contact luliet@asteriskllc.com for a registration form.



Micro-audit

This section of the Medical Gas Bulletin lists small steps you can take each month to improve your medical gas management system. These steps are not designed to be a full audit, but rather small steps to sample your compliance.

For this month, simply do these items:

- 1. **Filling Procedures** Copy the fill procedure from the SOPs and watch a cylinder filling operator actually perform the procedure. This is the same technique the FDA uses to see if we are following our fill procedures.
- 2. **Documented Training** Complete a training record for the cylinder filling operator that was observed. Attach a copy of the completed SOP to the training record.

Tom Badstubner GAWDA Medical Gas Consultant

Telephone: 508-883-0927

Fax: 508-883-3558

Email: tom@asteriskllc.com